

## Fuel Level Probe Type CS-27/RS/U

- ✓ Measuring range 0÷800 mm H<sub>2</sub>O
- ✓ Ministry of Transport Type Approval  
Certificate No.  
E20 10R-03 25 17

### Function

The CS-27 Fuel level probe is used to measure fuel level in the tanks of motor vehicles, working-machines and locomotives. The probes have been officially approved by the Ministry of Transport.

### Structure and Operation


The measurement of fuel level with the CS-27 probe is performed with the use of a simple relation between the height of liquid column and the produced hydrostatic pressure. The probe is composed of two parts: the sensing element and the electronic element, placed inside a steel rod, and aluminum housing. The steel rod is fixed to an aluminum housing which may be sealed. The measuring element is a piezoresistive sensor, separated from the medium by a separating membrane. Pressure measuring is performed at the membrane of the submerged probe (5 mm above tank bottom). Depending on the type of tank (pressurized or non-pressurized tank), pressure measuring is related either to atmospheric pressure or pressure inside the tank.

### Assembly and Usage

The CS-27 probe is mounted to the tank cover. A detailed description of assembly is presented in Technical Documentation.

The probe is designed to be connected to the following recording devices:

- analog input data recorder – current or voltage (current or voltage analog output probe).
- recorder or PC computer equipped with a serial RS-232C port (digital output probe).



## Technical Specification

<b>Measuring range</b>	0÷800mm H <sub>2</sub> O (special ver. 0...200÷2000mm H <sub>2</sub> O)
<b>Pipe length L in tank</b>	800mm (special ver. L=200÷2000mm)
<b>Maximum overload</b>	≤ 100kPa
<b>Basic error</b>	≤ 0.16%
<b>Hysteresis, replicability</b>	≤ 0.05%
<b>Long-term stability</b>	≤ 0.1% for two years
<b>Working temperature range</b>	-25 ÷ 80°C
<b>Compensation temperature range</b>	-25 ÷ 40°C
<b>Output signal</b>	0 ÷ 10V ; 0 ÷ 5V, 0 ÷ 4.5V, 0 ÷ 2.5V 100 ÷ 3800 bit
<b>Power supply</b>	12 ÷ 36V for output = 0 ÷ 10V 8 ÷ 36V for output = 0 ÷ 5V 8 ÷ 36V for output = 0 ÷ 4.5V 3.3±0,1V for output = 0 ÷ 2,5V 3.3±0,1V for RS-232 output (RXD, TXD: range 0...3,3V) 6.0 ÷ 36V for RS-232 output (RXD, TXD: range 0...3,3V) 6.0 ÷ 36V for RS-485 output (A,B: range -7V...+12V)
Power voltage fluctuation error	0.05%
Housing protection degree	IP 68
Temperature fluctuation error	0.3% / 10°C

## Ordering

Standard versions:


**CS-27/RS/U** – measuring range: 0÷800mm H<sub>2</sub>O, output signal: 0÷10V, pipe length in tank L=800mm

**CS-27/RS-232** - measuring range: 0÷800mm H<sub>2</sub>O, output signal: 100÷3800 bit in standard RS-232, pipe length in tank L=800mm

**CS-27/RS-485** - measuring range: 0÷800mm H<sub>2</sub>O, output signal: 100÷3800 bit in standard RS-485, pipe length in tank L=800mm

Special versions:

**CS-27/RS/U / \_ / \_ / L= ... mm**



### Example 1:

Fuel level probe CS-26 standard version (measuring range 0÷800mm H<sub>2</sub>O, pipe length in tank L=800mm) with voltage output 0÷5V

**CS-27/RS/U/0...800/0÷5V/L=800mm**

### Example 2:

Fuel level probe CS-26 special version (measuring range 0÷1000mm H<sub>2</sub>O, pipe length in tank L=1000mm) with RS ÷ 232 output

**CS-27/RS-232/0...1000/100...3800/L=1000mm**

### Example 3:

Fuel level probe CS-25 special version (measuring range 0÷1000mm H<sub>2</sub>O, pipe length in tank L=1000mm) with RS-485t output

**CS-27/RS-485/0...1000/100...3800/L=1000mm**